## **TORKEL 900-series**

### **Battery Load Unit**





- Batteries can be tested in service
- Dynamic discharge technology full power at all voltages
- Safety in all details, e.g. detection of blocked airflow
- Real time monitoring during test
- Easy report function and calibration
- Easily expandable for larger battery banks using TXL extra load units
- BVM cell monitor control integrated in the system

#### **DESCRIPTION**

The TORKEL<sup>TM</sup> 900 series is used to perform load/discharge testing which is the only way to determine battery systems actual capacity. Together with the optional cell voltage logger, BVM, connected directly to the TORKEL 900, it becomes a complete, stand-alone, discharge test system.

TORKEL comes in three models, 910, 930 and 950, see table below

The high discharge capacity of TORKEL gives the opportunity to shorten the test time. Discharging can take place at up to 220 A, and if higher current is needed, two or more TORKEL units or extra load units, TXL, can be linked together. Tests can be conducted at constant current, constant power, constant resistance or in accordance with a pre-selected load profile.

Testing can also be carried out without disconnecting the battery from the equipment it serves. Via a DC clamp-on probe, TORKEL measures the total battery current while regulating it at a constant level. Battery systems can be plus or minus grounded or free floating.


The test results can be presented and edited on a PC using the included PC software "TORKEL Viewer.

#### **MODEL OVERVIEW**

TORKEL	910	930	950
Current (max)	110 A	220 A	220 A
Voltage (max)	300 V	300 V	500 V
BVM functionality	No	Yes	Yes
Charging measurement	No	Yes	Yes
Full report functionality	No	Yes	Yes

#### **APPLICATION EXAMPLE**

The TORKEL is connected to battery, the current and the voltage alarm levels are set. After starting the discharge, TORKEL keeps the current constant at the preset level. When the voltage drops to a level slightly above the final voltage, TORKEL issues an alarm. If the voltage drops so low that there is a risk for deep discharging the battery, TORKEL shuts down the test. If the power supply is interrupted the test will continue when power is restored. All values are stored in TORKEL and can easily be transferred via an USB-stick or ethernet cable to a PC for evaluation and print out.



Separate sensing cables (dashed lines) should be used to get accurate voltage measurements to offset the voltage drop caused by long current cables and/or high current.

### **TORKEL 900-series**

## **Battery Load Unit**

#### **FEATURES AND BENEFITS**

#### 1. TXL STOP

Output used for stop discharging from an external device (e.g. TXL). Galvanically isolated.

#### 2. SERVICE

Connector for service purposes only.

#### 3 ALARM

Output equipped with a relay contact for triggering an external alarm device.

#### 4. DC OUT

9 V output for external current clamp.

#### 5. IEXT≤1V

Input used to measure current in an external path by means of a clamp-on probe or a current shunt.

#### 6. Display

Touch screen 7"

#### 7. BVM1, BVM2

USB connections for BVM units.

#### 8. USB connection

For USB memory stick.

#### 9. Ethernet connection

For reports connected to PC

#### **10. EMERGENCY STOP**

Push to stop.

Reset by turning it cloch-wise

#### 11. Control knob

For entering settings etc. Press to confirm a setting.


Megger.

### 12. Buzzer

For alarms.

#### 13. ON/OFF switch





### 4. 🖳

Protective ground (earth) conductor terminal

#### 15. MAINS

Connector for mains supply.

#### 16. +

Connection terminal (+) for the battery (or other DC source).

#### 17. VOLTAGE SENSE

Input for sensing voltage at the battery terminals. Impedance to the battery current terminals is >1  $M\Omega$ .

#### 18. -

Connection terminal (-) for the battery (or other DC source).

### **TORKEL 900-series**

## **Battery Load Unit**

#### **SPECIFICATIONS TORKEL 900-SERIES**

Specifications are valid at nominal input voltage and an ambient temperature of +25°C, (77°F). Specifications are subject to change without notice.

#### **Environment**

Application field The instrument is intended for use in high-voltage

substations and industrial environments.

**Temperature** 

Operating  $0^{\circ}\text{C to } +50^{\circ}\text{C } (32^{\circ}\text{F to } +122^{\circ}\text{F})$ 

Power derating at temperatures over +35°C

(+95°F)

**Storage &**  $-40^{\circ}\text{C to } +70^{\circ}\text{C } (-40^{\circ}\text{F to } +158^{\circ}\text{F})$ 

transport

Humidity 5% – 95% RH, non-condensing

Shock/Vibration/Fall

Instrument only ETSI EN 300 019-2-7 class 7M2

Instrument in ISTA 2A

transport case

Altitude

Operating 3000 m (10000 ft) Storage 10000 m (33000 ft)

Encapsulation IP20

class

**CE-marking** 

 LVD
 2014/35/EU

 EMC
 2014/30/EU

 RoHS
 2011/65/EU

General

Mains voltage 100 – 240 V AC, 50/60 Hz

Power 200 W (max)

consumption

Power 40 ms (max)

in terruption

**Protection** Thermal cut-outs, Automatic overload pro-

tection, Emergency stop button

**Dimensions** 519 x 315 x 375 mm, (20.5" x 12.4" x 14.7")

Weight 19.5 kg (43.0 lbs) instrument

31.9 kg (70.3 lbs) incl. standard transport case

39,2 kg (86,4 lbs) incl. large transport case

and cables

**Display** 7" LCD, Capacitive touch screen

Available Czech, English, French, German, Romanian,

languages Russian, Spanish, Swedish

Number of test 30 (max)

files

Test time

240 h (max)

#### Measurement section

#### **Current measurement**

Display range 0.0 to 2999.0 A

**Basic inaccuracy**  $\pm (0.5\% \text{ of reading } \pm 0.1 \text{ A})$ 

Resolution 0.1 A

#### Internal current measurement

Range

TORKEL 910 0 to 110 A
TORKEL 930/950 0 to 220 A

#### Input for clamp-on probe

Range 0 to 1000 mV DC

**mV/A-ratio** 0.30 mV/A to 100.00 mV/A

Input impedance >1 MΩ

Voltage measurement

Voltage 0 to 500 V DC

Inaccuracy  $\pm (0.5\% \text{ of reading } \pm 0.1 \text{ V DC})$ 

Resolution 0.1 V

Sample rate 10 Hz, Values are saved when change is >10 mV

**Time measurement** 

Inaccuracy  $\pm 0.1\%$  of reading  $\pm 1$  digit

**Load section** 


**Battery voltage**  $7.5 \text{ V to } 300 \text{ V}^{1)}/500 \text{ V}^{2)}$ 

Power 15 kW (max)

Load patterns Constant current, constant power, constant

resistance, current or power profile

Megger



#### **Constant I**

Range

TORKEL 910 0 to 110.0 A TORKEL 930/950 0 to 220.0 A Inaccuracy  $\pm (0.5\% +0.2 \text{ A})$ 

Resolution 0.1 A

Ripple max 0.5 A peak

Constant R

Range300 mΩ to 3 kΩInaccuracy±1% typicalResolution100 mΩ

**Constant P** 

Range 0 to 15 kW Inaccuracy ±1% typical Resolution 10 W

**Inputs** 

+ 7.5 to 300  $V^{(1)}$  7.5 to 500  $V^{(2)}$ 

I EXT  $\leq$  1 V 1 V DC, 300 V DC to ground

**VOLTAGE SENSE** Impedance to the current terminals is >1 M $\Omega$ 

**Outputs** 

ALARM

Relay contact 28 V DC, 8 A, 240 V AC, 8 A

Devices higher than Cat II must not be at-

tached

TXL STOP

**Relay contact** 250 VDC, 0.28 A, 28 VDC, 8 A, 250 VAC, 8 A

**9 V DC** 9 V DC, ±7% max 100 mA

**Communication ports** 

BVM1 BVM2 USB connection for BVM units

USB connection for USB memory

子 For reports connected to PC

1) TORKEL 910 and 930

2) TORKEL 950

## **M**egger.

## **TORKEL 900-series Battery Load Unit**

#### **SPECIFICATIONS TXL830/850/865/870/890**

Specifications are valid at nominal input voltage and an ambient temperature of +25°C, (77°F). Specifications are subject to change without notice.

#### **Environment**

Application field The instrument is intended for use in high-

voltage substations and industrial environ-

**Temperature** 

 $0^{\circ}$ C to +40°C (32°F to +104°F) Operating Storage & -40°C to +70°C (-40°F to +158°F)

transport

Humidity 5% – 95% RH, non-condensing

**CE-marking** 

LVD 2014/35/EU **EMC** 2014/30/EU **RoHS** 2011/65/EU

General

100 – 240 V AC, 50/60 Hz Mains voltage

Power 75 W (max)

consumption

Protection Thermal cut-outs, automatic overload

protection

**Dimensions** 

Instrument 210 x 353 x 600 mm (8.3" x 13.9" x 23.6") 710 x 310 x 520 (28" x 12.2" x 20.5") Transport case Instrument 13 kg (29 lbs) 21,4 kg (47 lbs) Weight

with transport case

#### **Load section**

	Voltage (DC) max.	Current max.	Power max.
TXL830	28 V	300 A	8.3 kW
TXL850	56 V	300 A	16.4 kW
TXL865	260 V (98 A max)	117 A	25.5 kW
TXL870	280 V (56 A max)	112 A	15.8 kW
TXL890	480 V (32 A max)	62 A	15.4 kW

Internal resistance, 3-position selector

	Position 1	Position 2	Position 3
TXL830	0.275Ω	0.138 Ω	0.092 Ω
TXL850	0.55 Ω	0.275 Ω	0.184 Ω
TXL865	2.65 Ω	5.05 Ω	0.12 Ω
TXL870	4.95 Ω	2.48 Ω	1.24 Ω
TXL890	14.10 Ω	7.05 Ω	3.52 Ω

#### Maximal currents, 3-position selector 1)

#### Position 1

	-			
	Current	Voltage	Cells	Cell voltage
TXL830	100 A	27.6 V	12	2.3 V
28 V max	78.5 A	21.6 V	12	1.8 V
TXL850	100 A	55.2 V	24	2.3 V
56 V max	78.5 A	43.2 V	24	1.8 V
TXL865	93.7 A	248.4 V	108	2.3 V
260 V max	73.4 A	194.4 V	108	1.8 V
TXL870	50.1 A	248.4 V	108	2.3 V
280 V max	39.2 A	194.4 V	108	1.8 V
TXL890	32.3 A	469.2 V	204	2.3 V
480 V max	26.0 A	367.2 V	204	1.8 V

#### Position 2

	Current	Voltage	Cells	Cell voltage
TXL830	200 A	27.6 V	12	2.3 V
28 V max	156 A	21.6 V	12	1.8 V
TXL850	200 A	55.2 V	24	2.3 V
56 V max	156 A	43.2 V	24	1.8 V
<b>TXL865</b> 260 V max	49.2 A	248.4 V	108	2.3 V
	38.5 A	194.4 V	108	1.8 V
TXL870	50.1 A	124.2 V	54	2.3 V
280 V max	39.2 A	97.2 V	54	1.8 V
TXL890	35.2 A	248.4 V	108	2.3 V
480 V max	27.8 A	194.4 V	108	1.8 V

#### **Position 3**

	Current	Voltage	Cells	Cell voltage
TXL830	300 A	27.6 V	12	2.3 V
28 V max	235 A	21.6 V	12	1.8 V
TXL850	300 A	55.2 V	24	2.3 V
56 V max	235 A	43.2 V	24	1.8 V
<b>TXL865</b> 14 V max	115 A	13.8 V	6	2.3 V
	90 A	10.8 V	6	1.8 V
<b>TXL870</b> 140 V max	100 A	124.2 V	54	2.3 V
	74.8 A	97.2 V	54	1.8 V
<b>TXL890</b> 250 V max	70.5 A	248.4 V	108	2.3 V
	55.2 A	194.4 V	108	1.8 V

1) The data examples apply to lead batteries.

## **TORKEL 900-series Battery Load Unit**

## Megger.

#### **OPTIONAL ACCESSORIES**

#### **Extra loads**



#### **BVM - Battery Voltage Monitoring**



#### Clamp-on-probe



#### Cable set Torkel 930/950



#### **Extension cables**





#### **Sensing leads**



#### **PowerDB**


PC software for BVM and TORKEL 800 / 900-series. For BVM and TORKEL 800 series it works for controlling, data management and report handling, for TORKEL 900-series only for data management and reporting.

## **TORKEL 900-series Battery Load Unit**

# Megger.

#### **INCLUDED ACCESSORIES – TORKEL 910**

#### Cable set



#### **Ground Cable**




#### **INCLUDED ACCESSORIES – TORKEL 930/950**

#### Cable set



#### **TORKEL Viewer**



	-01	RDERING
Item	U	Cat. No.
TORKEL 910		
Incl. transport case <b>Standard</b> 1) and	d accessories:	
Mains cable	a decessories:	
Cable set, 2 x 3 m, 25 mm <sup>2</sup>	GA-00550	
Soft case for cables	GD-00360	CC 10100
Incl. transport case <b>Large</b> 2) and acc		CS-19190
Mains cable		
Cable set, 2 x 3 m, 25 mm <sup>2</sup>	GA-00550	
	G/1 00330	CS-19191
<b>TORKEL 930</b> Incl. transport case <b>Standard</b> <sup>1)</sup> and	l accessories:	
Mains cable	accessories.	
Cable set, 2 x 3 m, 70 mm <sup>2</sup>	GA-09550	
Soft case for cables	GD-00360	
TORKEL Viewer	CS-8010X	
USB memory stick	HF-10020	66 40200
		CS-19390
Incl. transport case <b>Large</b> 2) and acc	cessories:	
Mains cable		
Cable set, 2 x 3 m, 70 mm <sup>2</sup>	GA-09550	
TORKEL Viewer	CS-8010X	
USB memory stick	HF-10020	CS-19391
TORKEL 950		
Incl. transport case <b>Standard</b> 1) and	d accessories:	
Mains cable		
Cable set, 2 x 3 m, 70 mm <sup>2</sup>	GA-09550	
Soft case for cables	GD-00360	
TORKEL Viewer	CS-8010X	
USB memory stick	HF-10020	CS-19590
Incl. transport case <b>Large</b> 2) and acc	cessories:	
Mains cable		
Cable set, 2 x 3 m, 70 mm <sup>2</sup>	GA-09550	
TORKEL Viewer	CS-8010X	
USB memory stick	HF-10020	CS-19591
	5551	
Included in all models above:		GC-30060
Ground cable, 5 m (16 ft) 2.5 mm <sup>2</sup>		GC-30060
	FI (no cables)	GC-30060 GD-00954

NFORM	MATION	
Item		Cat. No.
Cable 2x3m,	set , 25 mm², female/clamp. 110 A. 3.0 kg (6.6 lbs)	GA-00550
	sion cable on for GA-00550, 2x3m, 25 mm², male/female	GA-00552
	50 mm <sup>2</sup> , female/clamp 220 A. 5.0 kg (11 lbs)	GA-00545
	set, high rating n, 70 mm², female/fork. 270 A. 5.0 kg (11 lbs)	GA-09550
	sion cable, high rating on for GA-09550, 2x3m, 70mm², male/female	GA-09552
	<b>g lead set</b> asuring voltage at battery terminals. 2 x 5 m t)	GA-00210
	mp-on probe, 1000 A asure current in external circuit	XA-12991
	olphin clips, Power & signal connectors, supplies, Connection cables and Carrying case	
BVM1	<b>50,</b> System of 16 BVM units	CJ-59092
BVM3	<b>00,</b> System of 31 BVM units	CJ-59093
BVM6	<b>00,</b> System of 61 BVM units	CJ-59096
Incl. Do	<b>pecial 600 V</b> , System of 46 BVM units <sup>3)</sup> Olphin clips, Power & signal connectors, Ouplers, Power supplies, Connection cables and	
	ng case.	CJ-59198
	Single unit ontrol cable black RJ45 0.5m (1.6 ft)	CJ-59090
	sion cable ion lead for connecting BVM unit to battery, 1.6 ft)	04-30050
3) The T over !	ORKEL 950 can handle a maximum of 500 V. Bar 500 V and up to 600 V can be tested with BVM a cation on a computer.	ttery systems

1) Transport case **Standard**, Size: 670x400x510 mm, (26.4x15.7x20.1")
2) Transport case **Large**, Size: 795x400x510 mm, (31.3x15.7x20.1")



Mains cable

TXL830 Extra load

TXL850 Extra load

TXL865 Extra load

TXL870 Extra load

TXL890 Extra load

Incl. Cable set GA-09550, 2x3 m 70 m<sup>2</sup>\*)

Incl. Cable set GA-09550, 2x3 m 70 m<sup>2</sup>\*)

Incl. Cable set GA-00550, 2x3 m 25 m<sup>2\*</sup>)

Incl. Cable set GA-00550, 2x3 m 25 m<sup>2</sup>\*)

Incl. Cable set GA-00550, 2x3 m 25 m<sup>2</sup>\*)

\*) Control leads 2 x 2 m (6.5 ft), Transport case.

Megger Sweden AB Box 724 SE-182 17 Danderyd SWEDEN ZI-CS01E • Doc. CS033664JE • 2021 Subject to change without notice Megger Sweden AB Registered to ISO 9001 and 14001 The word 'Megger' is a registered trademark

jger.



BS-59093

BS-59095

BS-59096

BS-59097

BS-59099